

How to use and care for your Quickset Adjustable Torque Screwdriver

Tool Specification

Models: All models

(QS Minor: 0.2 – 1.2 Nm, QS 6: 1.0 – 6.0 Nm, QS 9: 4.0 – 9.0 Nm)

Accuracy: +/- 6% of Torque Setting

ISO 6789 Class: Type 2, Class D

Calibration Period: Every 12 Months or 5000 cycles (minimum)

Mechanism: Slipping - Incorrect tightening is impossible



At the set torque, the handle rotates through an angle of 60° before resetting.



Safety & Maintenance

- ✓ This Torque Tool is a precision instrument and should be used for its intended purpose only
- ✓ Only hold the tool using the handgrip
- ✓ Always ensure that the tool is in correct alignment with the fastener
- ✓ Torque tools should be regularly calibrated and inspected to ensure correct operation
- ✓ Ensure the tool is clean and free from oil, grease and water before use
- ✗ Do not use extension bars to increase the leverage of the handle
- ✗ Never dip into cleaning fluid or petroleum

How to adjust your Torque Screwdriver

To adjust the torque setting:

Engage the adjusting mechanism by pressing down on the black adjusting knob.



To increase torque:

Rotate the handle clockwise until the required torque is selected on the calibrated scale.



To reduce torque:

When adjusting, always approach the required torque from a lower setting.

Rotate the handle anti clockwise passed your setting, then increase torque to the required value.



To increase leverage:

Optional lock on T-Bar for larger models of screwdrivers, provides extra leverage when required. (Order Code P29530).

This fits into the 1/4" Square Drive (SD) in the end of the handle.



To use Torque Screwdriver:

The Quickset Screwdriver is designed

for use with sockets, screwdriver bits and blades.

After use, set the screwdriver at the lowest setting on the scale.



Service Information

Regular servicing of your Torque Tool by competent personnel is important to ensure it continues to perform correctly.